



**POWER CORD:**  
1 – 30 Amp  
Dryer Cord

**ECOPLUS  
DIGITAL TIMER**

**TRIGGER CABLE**

**BREAKERS:**  
1 – 20 Amp Breaker  
240 Volt  
1 – 10 Amp Breaker  
120 Volt

**RECEPTACLES:**  
4 – 240 Volt Receptacles  
(supplies up to 4 - 1000 watt light systems)

**RECEPTACLES:**  
2 – 120 Volt Receptacles  
(supplies accessories such as fans or light movers)

This unit allows the user to run up to 4 -1000 watt light systems and up to 10 amps of accessories from the same timer.  
The timer controls the power supply to the receptacles.

Setup for 30 Amp Timer Box:

1. Have a certified electrician install the NEMA receptacle for a 10-30P.
2. For timer instructions and settings see included instruction sheet.
3. Plug included timer into a standard 120V outlet. Plug 120V "trigger cable" into timer.  
This EcoPlus timer will now control the functionality of your Timer Box.



**POWER CORD:**  
1 – 50 Amp Range Cord

**ECOPLUS DIGITAL TIMER**

**TRIGGER CABLE**

**BREAKERS:**  
1 – 20 Amp Quad  
Breaker 240 Volt  
1 – 10 Amp Breaker  
120 Volt

**RECEPTACLES:**  
8 – 240 Volt Receptacles  
(supplies up to 8 - 1000 watt light systems)

**RECEPTACLES:**  
2 – 120 Volt Receptacles  
(supplies accessories such as fans or light movers)

This unit allows the user to run up to 8 - 1000 watt light systems and up to 10 amps of accessories from the same timer.  
The timer controls the power supply to the receptacles.

Setup for 50 Amp Timer Box:

1. Have a certified electrician install the NEMA receptacle for a 14-50P.
2. For timer instructions and settings see included instruction sheet.
3. Plug included timer into a standard 120V outlet. Plug 120V "trigger cable" into timer.  
This EcoPlus timer will now control the functionality of your Timer Box.

Troubleshooting:

1. What if I plug my timer box in and I get no power to the unit?
  - A. Check the fuse
  - B. Check the breaker in your main panel
  - C. Have a certified electrician check your receptacle to make sure it is operating properly
2. My timer is working but I am not getting power to some of my receptacles.
  - A. Make sure all of the breakers on the timer box are in the on position.



Vancouver, WA  
Sunlight Supply®, Inc.  
www.sunlightsupply.com

## WARRANTY SERVICE: *Please read warranty information first*

If after reviewing the troubleshooting tips the timer box will still not work, you should return the timer box to the dealer where you purchased it. They will be able to further evaluate the timer box and test its various components and quite possibly will be able to identify and/or fix any problems. If the dealer is unable to fix the timer box, they will return it to us for factory repair.

If there are no dealers in your area, you may contact us directly for technical support. If we cannot help you resolve the problem over the phone, we will issue you a RMA # (return merchandise authorization) authorizing you to return the timer box to us for factory reconditioning (if the unit is under warranty). Contact our closest service center for an RMA and shipping address. Complete the form below and include it with your timer box. Also please write the RMA # on the outside of the box.

Once we receive the timer box back, we will repair it within 48 hours (business) and return it to you freight prepaid via UPS ground shipment.

**PLEASE PACKAGE THE TIMER BOX CAREFULLY IN ITS ORIGINAL PACKAGING. IF IT IS DAMAGED IN SHIPMENT WE CANNOT BE RESPONSIBLE.**

Include the following if returning directly to Sunlight Supply®, Inc.

- Proof of purchase
- This completed form
- RMA # on the outside of the box



Return Merchandise Authorization Number (Required): \_\_\_\_\_

Company Name: \_\_\_\_\_

Contact Name: \_\_\_\_\_

Address: \_\_\_\_\_

Phone #: \_\_\_\_\_

Email address: \_\_\_\_\_

What is the nature of the problem?

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Send to your nearest location – shipping address will be given when the RMA # is issued:

**Vancouver, WA (360) 883-8846**

**Ontario, CA (909) 930-1990**

**Nashville, TN (615) 773-5950**